

# SACE Tmax XT

UVR - Sganciatore di minima tensione cablato e non cablato, per interruttore XT1-XT2-XT3-XT4 fisso/rimovibile.

UVR - Wired and non-wired undervoltage release for XT1-XT2-XT3-XT4 fixed/plug-in circuit-breakers.



UVR - Unterspannungsauslöser, verdrahtet verdrahtet und nicht verdrahtet, für XT1-XT2-XT3-XT4 Leistungsschalter vom festen Typ/Steckbaren.

UVR - Déclencheur à minimum de tension câblé et non câblé, pour disjoncteur XT1-XT2-XT3-XT4 fixe/debrochable.

UVR - Relé de mínima tensión cableado y no cableado, para interruptor XT1-XT2-XT3-XT4 fijo/removible.


UVR - 用于XT1-XT2-XT3-XT4固定式/插入式断路器的带导线和不带导线欠电压脱扣器

XT1-XT2-XT3-XT4




1

Nel caso sganciatore e dima non siano assemblati, montarli come indicato.  
 In case release and template are not assembled, mount them as indicated.  
 Im Fall Auslöser und Schablone nicht montiert sind, montieren sie als angezeigt.  
 En cas déclencheur et gabarit ne soient assemblés, les assembler comme indiqué.  
 En el caso relé y plantilla no estén ensamblados, ensamblarlos como indicado.  
 如果脱扣器和辅助安装支架未装配在一起，请按图示进行安装。




2

FOR XT1 F - XT3 F ONLY




3

FOR XT2 F - XT4 F ONLY




4

FOR XT4 V-X ONLY




5

FOR XT2 - XT4 ONLY




6

FOR XT2 - XT4 ONLY




7

FOR XT1 3P ONLY




8

FOR XT3 3P ONLY




9




FOR XT2 - XT4 3P ONLY








10

FOR NOT CABLED ONLY


























Yu 480÷525 V ~



Yu 380÷440 V ~

