



SACE Tmax XT

SOR/PS-SOR - Sganciatore di apertura cablato e non cablato, per XT1-XT2-XT3-XT4 interruttore fisso/rimovibile .
SOR/PS-SOR - Wired and non-wired opening release for XT1-XT2-XT3-XT4 fixed/plug-in circuit-breakers
SOR/PS-SOR - Arbeitsstromauslöser, verdrahtet und nicht verdrahtet, für Leistungsschalter XT1-XT2-XT3-XT4 vom festen Typ/ Steckbaren.
SOR/PS-SOR - Déclencheur d'ouverture à émission câblé et non câblé, pour disjoncteur XT1-XT2-XT3-XT4 fixe/debrochable.
SOR/PS-SOR - Relé de apertura cableado y no cableado, para interruptor XT1-XT2-XT3-XT4 fijo/removible.
SOR/PS-SOR - 用于XT1-XT2-XT3-XT4 固定式/插入式断路器的带导线和不带导线分励脱扣器

XT1-XT2-XT3-XT4/III-IV




F-P	XT1-XT2-XT3-XT4	
	III	IV
SOR	OK	OK
PS-SOR	OK	OK
N°2 SOR or N°2 PS-SOR	NO	OK
SOR+UVR	NO	OK
SOR+YO2	NO	OK YO2(3P)+SOR(4P)
SOR+3Q	NO	OK SOR(3P)+3Q(4P)




2

FOR XT2 F - XT4 F ONLY




3

FOR XT4 V-X ONLY




4

FOR XT2 - XT4 ONLY




5

FOR XT2 - XT4 ONLY



6

FOR XT1 3P ONLY



7

FOR XT2 - XT4 3P ONLY

